

OVEN & GRILL CLEANER

Dissolves Grease

- Gel formulation clings to surfaces.
- Eliminates scraping.
- Cleans both warm and cold ovens.

A powerful, effective, spray-on, wipe clean oven cleaner that works quickly and is easy to use. Effective on warm or cold ovens, grills and drip pans. Even removes caked-on and heavily burnt greases. Minimizes the need for scouring when cleaning heavily soiled steel pots and pans. It's gel formula is safe to use on any metal.

Directions:

SHAKE WELL BEFORE USING

- 1. Turn off current in electric ovens and pilot lights in gas oven.
- 2. Cover floor under oven with newspapers.
- 3. Remove racks and other equipment from oven and clean these separately.
- 4. Remove cap and point valve opening toward surface to be cleaned. Hold can upright and spray 8" to 12" from surface.
- 5. Avoid contact with exterior trim and do not allow spray to penetrate electrical connectors or rear pilot lights.
- 6. Leave oven door open and let cleaner stay on 15-20 minutes. Wipe clean and then rinse with potable water.