

EPOXY-GRIP SPRAY COATING

CLEAR ANTI-SLIP COATING

Form: Aerosol Liquid

Color: Clear

Odor: Characteristic

•
•
•

Use **EPOXY-GRIP SPRAY COATING** On . . .

Steps

Showers

Ladders

Boats

Ramps

Loading Docks

Running Boards

Decks

DIRECTIONS:

PREPARATION: Surface must be clean and dry before painting. For best results, use when can is between 70° and 90°F. (21°and 32°C). Previously painted surfaces should be cleaned with a mild detergent, rinsed thoroughly and dried. Before initial application, a light etch or sanding is recommended. Test a small area for compatibility and adhesion. The coating is self priming on surfaces.

APPLICATION: Shake can at least one minute before and occasionally during use. Spray surface with steady, even strokes at a distance of 8 to 10 inches (20 to 25 cm). Several light coats give a better finish than one heavy coat. If clogging develops, turn spray button ¼ turn or remove and clean button slot. Do not stick objects into can opening. After painting, turn can upside down and spray for 2 seconds to clean spray button. Discard empty can in trash pick up. Do not incinerate or compact.

DRYTIME: Dries to the touch in approximately 30 minutes. Be sure the first coat is dry before applying a second coat. The rate of cure will vary with the film thickness, temperature and humidity. Allow 24 hours before opening to heaving foot traffic. Recoat in 3 to 6 months or as wear indicates.

SHARE CANADA

1691 Church Avenue, Winnipeg, MB R2X 2Y7

Phone: 1 800 665 7692 Fax: 1 800 563 8453